

Any questions? Call us on +353 (0)1 247 9007



Silent Alert Technical Update

New Pager Demonstration routine

All Silent Alert Pager's produced from 28th September 2011 include a new demonstration routine . The routine causes the Pager to activate each event in sequence to help familiarise users with the unique vibration pattern for each signal.

Simply move key B on the pager to the ON position, code a Universal Monitor as a Telephone using key 16 and activate the monitor. The routine will need to be cancelled by pressing and holding the fire key until the vibration stops.

To restore the pager to normal mode please remember to move key B on the Pager to the off position.



Telephone Buzz Buzz (pause) Buzz Buzz. As a telephone would ring.

Doorbell High frequency Buzz followed by a low frequency Buzz. Ding – Dong.

Person - Person A long Buzz followed by a long pause.

Baby Alarm Short Buzz, short pause then a longer Buzz. As in Wa- Waaa.

Car/Burglar Alarm Oscillating Buzz (high then low). Similar to a police siren.

Fire / CO Alarm Buzz Buzz Buzz. Similar to a smoke alarm.

Operating Range

