
# Quick start guide UM3A-HEAT-DETECTOR

## Wireless Heat Detector

#### Standard operation




# 2.


Press the heat detector test button whilst holding the alarm in the desired location.


Refer to the separate El instructions for the heat detector to determine the best position for the unit.

Check the Pager or SignWave has received the signal before fixing in place.


#### Any questions? Call us on +353 (0)1 247 9007







Silent Alert International




# Advanced settings UM3A-HEAT-DETECTOR

### Wireless Heat Detector



#### System channel override

Key 6 is for system channel override. If it is set, all SignWave and Pager units within range will activate when the heat detector triggers regardless of what system channel they are on. This can be used in multi occupancy dwellings where a number of systems are working independently of each other but it is beneficial to have communal heat detector cover.



#### Changing the system channel code

**NOTE.** In most cases it is not necessary to change the system code. However, when one or more systems are in close proximity, system codes can be used to avoid interference from other Silent Alert systems using up to a maximum of 16 system channels.

The monitor is supplied with no system code switches set (system code 1). For reference this is the factory setting should you need to re-set the unit.

System codes can be set using key switches 1 - 4. The diagram to the right shows the 16 possible combinations.

Be sure that the same system code is set on the receiver to be used and any other monitors in that system.

1	2	3	4	
			*******	
1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8	
5	6	7	8	
1 2 3 4 5 6 7 8	12345678	12345678	1 2 3 4 5 6 7 8	
9	10	11	12	
1 2 3 4 5 6 7 8	12345678	12345678	1 2 3 4 5 6 7 8	
13	14	15	16	
1 2 3 4 5 6 7 8	1 2 3 4 5 6 7 8	12345678	1 2 3 4 5 6 7 8	

Any questions? Call us on +353 (0)1 247 9007