



Quick start guide CH3A-2205-IN

Alarm Clock Charger




Any questions? Call us on +353 (0)1 247 9007




1.  Connect the power supply to the unit and the plug adaptor into a 13 Amp mains socket.

The display will switch on and the charger will power up. Use the strain relief in the charger base to secure.

2.  The pillow pad should be fitted at this stage if required.

Use the strain relief in the charger base to secure.


3.  Dock the pager in to the charger. The battery key on the pager & the snooze key on the charger will light green briefly upon docking confirming the pager is docked correctly.

If a pillow pad is fitted it will vibrate three times when the pager is docked.

We recommend a full 24 hour charge before using our equipment.

In an emergency a few hours charge may be sufficient for short time use but this is not advised.

Alarm clock control keys




Setting the time



Press and hold the "time set" key.



Use the "hour advance" and "minute advance" keys to enter the correct time.



Release the "time set" key to finalise the setting.


Setting the alarm time



Press and hold the "alarm set" key.




Use the "hour advance" and "minute advance" keys to enter the desired alarm time.



Release the "alarm set" key to finalise the setting.

Setting the alarm




Press and hold the "alarm set" key.


The pillow pad will vibrate 3 times when the alarm is switched on. Also, the bell & snz symbols will display on the clock.

If the pillow pad is not fitted the charger will beep three times.

Alarm set indicator



When the alarm goes off the charger will beep and the pillow pad will vibrate.



To deactivate the alarm press the alarm ON/OFF button.

To delay the alarm for 4 minutes press the snooze button

